



Pneumatic Garage & Shop Stool

Assembly Instructions

24914

PLEASE READ INSTRUCTIONS CAREFULLY






Tools Needed:

- 1/2" / 13mm Socket Wrench
- 9/16" / 14mm Wrench (or) Adjustable Wrench
- Phillips Head #2 Screwdriver

Parts List:

- | | |
|-------------------|----------------------------|
| A. Leg Sleeve | F. Plastic Screws (4) |
| B. Leg Connection | G. Foot Ring |
| C. M8 Bolts (8) | H. M6 Bolts (4) |
| D. M8 Nuts (8) | I. M6 Nuts (4) |
| E. Legs (4) | J. Hydraulic Cylinder |
| | K. Height Adjustment Lever |

Bolt Kit Includes:


- | | | |
|----------------|---|-------------|
| M8 Bolts |  | (8 of Each) |
| M8 Nuts |  | (8 of Each) |
| M6 Bolts |  | (4 of Each) |
| M6 Nuts |  | (4 of Each) |
| Plastic Screws |  | (4 of Each) |

Assemble on a level surface.


Step 1. Attach Leg Sleeve (A) to Leg Connection (B). Insert M8 Bolt (C) through the aligned holes. Fasten using M8 Nut (D).

Repeat with 3 remaining Leg Sleeves.


Do not tighten completely.




Step 2. Insert Leg (E) into Leg Sleeve (A). Fasten using Plastic Screw (F). Repeat process with 3 remaining Legs.




Step 3. Attach Foot Ring (G) to the inside of Leg (E).
Insert M6 Bolt (H) through the aligned holes.
Fasten using M6 Nut (I). Repeat process,
attaching ring to inside of remaining Legs.
Do not tighten completely.



Step 4. Insert the large end of the Hydraulic Cylinder (J) into center of Leg Connection (B).



Step 5. Place Seat (K) over the Hydraulic Cylinder (J).
Raise the Height Adjustment Lever (L) and push
the seat to secure seat on the cylinder.



Step 6. (Not Shown as an Illustration)
Tighten all nuts equally at this time,
alternating sides in the process.